

## EXPONA Design Flooring

EXPONA  
COMMERCIAL

## Supplier

## Wet adhesives

ARDEX GmbH

AF 2224  
AF 140EXPONA  
DESIGN

Bostik GmbH

Power Elastic

EXPONA  
DOMESTICBOTAMENT  
Systembaustoffe GmbH & Co. KGBOTAMENT K 530  
BOTAMENT K 530 Faser

Forbo Erfurt GmbH

528 Eurostar Allround  
643 Eurostar FibreEXPONA  
LIVING

G.A. Kiesel GmbH

Okatmos star 110

MAPEI GmbH

Ultrabond Eco V4 SP  
Ultrabond Eco 4 LVT

PCI Augsburg GmbH

PKL 326  
K 188 S

Sika Deutschland GmbH

Durocoll

Uzin Utz AG

KE 66

Wakol GmbH

D 3318

WULFF GmbH u. Co. KG

Supra-Strong, Multi-Strong  
Ultra-Strong

The adhesives shown here require a consistently absorbent base.

The design floor covering has to be rolled or rubbed down carefully after it is installed.

All the adhesives that we recommend must be used in accordance with the respective manufacturer's specifications.

Only those adhesives are suitable for the application and use.

Any adhesives that are not listed in this recommended list have not been tested. They have not been tested for compatibility with our products.

**Note:**

**A thermosetting resin adhesive must be used when installing design floor coverings in conservatories or rooms with large banks of windows with a high level of solar radiation.**