

EXPONA Design Flooring

EXPONA FLOW

Pressure-sensitive adhesives for non-absorbent subfloors only
Bostik's Best
Ultrabond Eco 350
Emiclassic
K 188 E
KE 2000 S SWITCHTEC Sigan 1, 2 *

^{*} The suitable subfloors for Sigan 1, 2 are indicated at www.uzin-utz.com.

The use of pressure-sensitive adhesives reduces the dimensional stability of floor coverings and increases the joint size.

The flooring must be carefully rolled or pressed down after being laid.

All adhesives recommended by us must be used in accordance with the manufacturer's instructions.

Only these adhesives are suitable for use.

Any adhesives not included in this list of recommended adhesives have not been tested. Their compatibility with our products has not been tested.